

Inside Lifts

Installation & Owner's Manual

 **Harmar.**
America's Lift Leader™

www.harmar.com | 800-833-0478



AL215 Axis I

Single Axis Inside Lift

Capacity: 250 lbs.



AL225 Axis II Lift

2-Axis Inside Lift

Capacity: 250 lbs.



AL425 Axis II

2-Axis Inside Lift

Capacity: 400 lbs.



AL435 Axis III

3-Axis Inside Lift

Capacity: 400 lbs.



AL435T Axis III

Truck Lift

Capacity: 400 lbs.



Read and understand this manual thoroughly before attempting to install or operate the lift. If you have any questions, please contact your Authorized Harmar Dealer or Harmar's Technical Service Department.

P 800-833-0478 | F 866-234-5680 | TECH@HARMAR.COM

Dealer Name & Contact Information:

Serial # of Your Lift:

Contents

Section 1 : Owner

OPERATING YOUR LIFT

Using Your Lift	3
Safety	7
Maintenance.....	8

Section 2: Installer

PREPARATION

Understanding the Manual	9
Installation Overview	10
Tools Required	11
Unpacking the Lift.....	12

INSTALLATION

Wiring the Vehicle	13
Trial Fit Procedure.....	16
Base Installation	
Flat Floor	18
3rd Row Folding Seats	20
Exploded View, 3rd Row Assembly ...	22
Truck Bed	23
Lift Installation	25
Lift Adjustments.....	27
Height	27
Pitch.....	28
Rotation.....	28



Harmar.
America's Lift Leader™

DOCKING DEVICES	14
-----------------	----

TROUBLESHOOTING	31
-----------------	----

EXPLODED VIEWS

AL215.....	33
AL225	34
AL425.....	35
AL435.....	36
AL435T	37
AL215 & AL225 Arm.....	38
AL425 Arm	39
AL435 Series Arm	40
AL225 / AL425 / AL435 Series Base....	41

ELECTRICAL DIAGRAM	42
--------------------	----

WARRANTY	43
----------	----

NOTE: The following symbols indicate areas where you should take special care in order to avoid danger to individuals or property.



WARNING

Hazardous situation to avoid possible serious injury to installer or user.



CAUTION!

Hazardous situation to avoid serious damage to property.

1. **Park power chair or scooter** ready to be picked-up along the side and parallel to the vehicle. [Figure 3-1]

**CAUTION!**

Always make sure the vehicle's parking brake is firmly set.

2. **Open the vehicle's hatch.** Fold the seat-back of the chair or scooter. [Figure 3-2]

**CAUTION!**

Keep hands and feet away from the bottom of the chair or scooter as it is being lifted.

3. **Press the 'OUT' button** on the hand controller to rotate the arm outside the vehicle. [Figure 3-3]

NOTE: For the **AL215**, manually rotate the lifting arm outside of the vehicle.



Figure 3-3




Figure 3-4



Figure 3-1



Figure 3-2

**CAUTION!**

DO NOT expose hand control to rain or snow. If the lift is installed in an open truck bed, keep the control inside the cab when not in use.

Also, place the harness connector within the base cover to protect it from the environment.

AL435 series lifts (AL435 / AL435T) have an "EXTEND" button which can be pressed to extend the arm outside, providing more clearance past the vehicle for wider chairs or scooters. [Figure 3-4]



CAUTION! Inspect lifting strap prior to use.



CAUTION! Ensure the lifting strap is secure and that it points straight down. Failure to do so could result in the chair or scooter swinging, causing damage to operator, chair or vehicle.



Figure 4-1

4. When the lift has cleared the vehicle, press the "DOWN" button to lower the strap.

Attach the docking device supplied with your lift. Attach the strap hook to the docking device. [Figure 4-1]



Figure 4-2

5. Press the "UP" button to begin raising the power chair or scooter. [Figure 4-2]

NOTE: On AL435 series lifts, you can press the "RETRACT" button to shrink the radius for rotating into the vehicle. This is especially helpful for wider chairs or scooters and for narrower rear vehicle openings. [Figures 4-3]




Figure 4-3

- 6. When the chair is raised enough to clear the bumper/threshold, rotate the chair or scooter into the vehicle by pressing the "IN" button. [Figure 5-1]**

NOTE: For the **AL215** manually rotate the lifting arm inside the vehicle.

- 7. When the chair or scooter is fully inside the cargo area, press "DOWN" until the chair or scooter is placed firmly on the floor.**

Leave some tension on the strap during transport to eliminate movement of the chair or docking device.

- 8. To unload, reverse the process.**



CAUTION!

DO NOT expose hand control to rain or snow. If the lift is installed in an open truck bed, keep the control inside the cab when not in use.




Figure 5-1

continued




Figure 6-1




Figure 6-2




Figure 6-3

When the lift is not being used, press the UP button to run the strap up and keep the hook from swinging.

[Figures 6-1 thru 6-3]



CAUTION!

Tighten the strap only enough to prohibit the lift from rotating. Over-tightening may cause damage to the strap and/or lift.

NOTE: The **AL215** is manually rotated and does not have a lock to keep it from rotating. In order to prevent it from moving when not in use, we recommend that the strap be run down by holding the DOWN button until the hook has reached the gusset nearest the side wall of the vehicle. Latch the hook on the gusset and press the UP button until the strap is taut, as shown for passenger side applications.

[Figure 6-4]



CAUTION!

Always hook the strap to the gusset and run taut when **AL215** is not in use.




Figure 6-4

**CAUTION!**

DO NOT operate this lift until your dealer has satisfactorily instructed you in its proper operation.

**WARNING!**

Check regularly before use for any worn, loose, or damaged parts of the lift.
[Figure 7-1]

Although your lift is designed and engineered for years of trouble-free use, regular use may result in some parts becoming loose or worn.

- If you notice any problems, **DO NOT USE THE LIFT!** Contact your mobility dealer or installer for repairs or have the strap replaced immediately.
- Use your Inside Lift only for loading and unloading the power chairs and scooters for which it is designed.
- If your particular application (vehicle & chair/scooter) changes, for example, if you buy a new car or change your power chair or scooter, consult your dealer or installer since the original equipment may not configure in the same way.
- **DO NOT** add to or modify any part of the lift system without first consulting the lift manufacturer.
- Any modifications may void warranties as well as compromise the structural integrity of the lift.



WARNING!
ALWAYS CHECK
THE LIFTING STRAP
BEFORE EACH USE
FOR DAMAGE
OR WEAR




Figure 7-1

**CAUTION!**

• Ensure the lifting strap is secure and taut when attaching the strap hook to your chair or scooter. Make sure the strap points straight down before lifting. Failure to do so could result in the chair or scooter swinging toward the operator or vehicle, causing damage.

• Avoid having hands and feet under the chair / scooter as it is loaded or unloaded.

• Stop lifting before the strap hook contacts the strap roller or frame. Contact will damage the lift. [Figure 7-2]
A properly adjusted lift will avoid contact.



Figure 7-2

• Ensure the chair / scooter is firmly sitting on the floor of the vehicle and not suspended by the lift during transportation. If the chair / scooter is not firmly on the floor, it may move during transport causing damage to the lift, vehicle, chair / scooter, or passengers.

Your Inside Lift has been designed and engineered to be as trouble-free as possible. But as with any mechanical device, it requires regular care while owning and using it.

ALWAYS check the lifting strap before use and while using the lift. If any wear or damage is noticed **DO NOT USE THE LIFT!** Contact the dealer or installer for repair. Failure to do so may result in serious injury or damage.

Schedule a preventative maintenance inspection with your dealer at least once a year on motors, lift frame, wiring harnesses, and all moving parts.

Check for paint chips and touch up any bare metal with a good gloss black enamel or lacquer to inhibit rust. This may be necessary more frequently if the lift is subjected to salt air or road salt.

Store hand control units inside the vehicle whenever possible. If the lift is installed in the back of a pickup truck, unplug the hand control after each use and store it inside the cab. Submerging the hand control in water will cause it to fail.

Read & Understand this Manual Prior to Installation or Operation.

Having an overall understanding of the lift and proper installation techniques will help you save time, energy and avoid possible injury.

If you do not understand any portion of installation or operation, please consult our technical service department or authorized mobility dealer. Do not attempt to install or use this lift with any hesitation or question. Serious injury or damage can result if proper procedures are not followed. We strongly recommend having a certified dealer install the lift, configure the docking device and instruct the user on correct operation as well as establish a Safety and Maintenance Schedule.

NOTE: The components of this lift are packaged as separate units that should be lifted out and installed individually.



WARNING! DO NOT attempt to pick up the entire lift box from the ground; **DO NOT** try to put the lift on or take off a vehicle alone.

INSTALLATION OVERVIEW

1. Trial Fit for Base Mounting Location

To install the lift, you'll most likely need to drill three holes in the vehicle's floor. Do not drill until you simulate the lift's range of motion inside the vehicle.

Also simulate the object to be loaded. Determine an accurate location for the lift while maximizing the remaining cargo area.

[Figure 10-1]




Figure 10-1

2. Vehicle Wiring Harness

Install the vehicle wiring harness first, power will be available to move the lift, making installation easier. [Figure 10-2]




Figure 10-2

3. Installing Lift Components

You'll install the base adapter in the chosen location based on the trial fit procedure. Install base of lift onto the base adapter, then install the lifting arm. [Figure 10-3]





Figure 10-3


TOOLS REQUIRED

Installations may vary to some degree, but below are the basic tools to have on hand for an Inside Lift installation.




BASE ADAPTERS & HARDWARE PACK

The base adapter for your specific application is included in the lift package.



BA00 Standard
(Used on any flat surface)



BA01R1 Stow 'n Go (Used with folding seats)



AL207 Leg Extension
(Required for some BA00 applications)

UNPACKING THE LIFT

Check the box contents. Review each part against the packaging checklist to ensure that all parts have been included.

If any parts are missing or damaged, immediately contact the dealer who sold the lift. Do not attempt to install or use a lift that has missing or damaged parts.

BASE ASSEMBLY & OFFSET POST

ARM ASSEMBLY

AL425		
AL225		
AL215		
AL435 or AL435T		

WIRING THE VEHICLE

Improper wiring is the #1 cause of problems in operating a vehicle lift. Follow the wiring instructions carefully

The vehicle wiring harness is located in the hardware pack. The harness is manufactured to comply with SAE J1128 requirements. It is approximately 23 feet long and will accommodate most vehicles.

1. Unwind the wiring harness and lay it flat.

One end of the harness has 2 covered pins. This is the lift end and goes to the rear cargo area where the lift mounts. *[Figure 13-1]*

The wiring harness is unassembled for easier installation. The end connector is included separately from the harness to enable the installer to run the wire under and through the vehicle with the smallest clearance possible.




Figure 13-1

DO NOT connect the red wire until the very end.

2. Route the wire harness beginning at the battery.

Attach the black wire to the negative terminal on the battery. *[Figure 13-2]*

continued




Figure 13-2

DO NOT attach the red wire until the very end of installation.

Wiring the Vehicle (con't)




Figure 14-1

3. Run the vehicle harness to the rear cargo area/trunk.

Run the wire under and through the vehicle whenever possible, gaining entry into the vehicle through the firewall. [Figure 14-1]

- DO NOT** run wiring where it can be snagged by road debris.
- DO NOT** run wiring near the gas tank.

IMPORTANT!

If the installation requires the wiring harness to run on the underside of the vehicle, route the harness away from the exhaust system, brake lines, fuel lines and gas tank. Avoid pinch points and sharp edges. Avoid locating the harness where it can be snagged by road debris.

If you want to run the harness under the vehicle, you will most likely need to drill a hole to get the wire into the rear cargo area/trunk. Use the supplied 3/8 grommet in the hole to protect the wire. If the harness is too long for the vehicle, coil the excess wire and secure it to the vehicle frame with the supplied cable ties.

- Do NOT** cut or shorten the harness.



Figure 14-2

4. When the harness is through the vehicle, remove the pin's protective tubing. [Figure 14-2]




Figure 14-3

5. Inspect the pin's retaining flanges.

The flanges may have been deformed while being run through the vehicle. These are critical to secure the pins inside the connector. Adjust as needed. [Figure 14-3]

Wiring the Vehicle (con't)

6. Flip open end connector's hinged retainer.

- Insert pins as shown. [Figure 15-1]
- Verify the wires cannot be pulled out by moderately pulling on the wires.
- Be sure rubber seals are inside the back of the connector.
- Close the hinged retainer.
- Plug connector into lift.




Figure 15-1

7. Attach red wire to the positive terminal on the battery. [Figure 15-2]




Figure 15-2

AL215



AL225



AL425



AL435



AL435T



TRIAL FIT PROCEDURE

The **AL215, AL225, AL425, AL435, AL435T** require a minimum of three holes to be drilled into the vehicle's floor to secure the base. The positioning is vital to the lift's successful installation and operation.

Before drilling any holes, ensure that the lift can be positioned to permit a full range of motion. [Figure 16-1]




Figure 16-1



Figure 16-2

1. Place the base in the vehicle's cargo area. Shown is passenger-side installation. [Figure 16-2] Driver's side is identical, but mirrored.

2. Fold the chair or scooter's seat back (or remove seat), preferably with the docking device attached, to roughly observe the chair's transportable dimensions. Measure length, width and height. [Figure 16-3]




Figure 16-3

Trial Fit Procedure (con't)

3. **With an assistant, place the lift on top of the base** in the extreme back corner of the cargo space. This will yield the greatest available loading area. Slide the arm onto the post. [Figure 17-1]




Figure 17-1

4. **Simulate each of the chair's dimensions** (length, width and height) while running the lift through its full range of motion in and out of the cargo area. [Figure 17-2]




Figure 17-2

5. **Verify that each of the measurements allows full range of motion** within the cargo area and the opening, mark the three locations to drill. [Figure 17-3]




Figure 17-3




Figure 18-1




Figure 18-2

BASE INSTALLATION / Flat Floor

After you know the lift position from the trial fit procedure, you are ready to drill three 3/8" holes in the locations you marked.

1. Drill Pilot Holes

- Choose a safe location to drill a single pilot hole from above in one of the three marked locations.
- Look under the vehicle and measure the specified distance from the pilot hole.
- If all is clear in that area continue to drill in remaining locations.
- Inspect all three pilot holes under the vehicle.
- If all clear, drill 3/8" holes in pilot locations. [Figure 18-1]



CAUTION!

Avoid vehicle wiring, fuel lines, fuel tanks, spare tires, etc. when drilling.



2. Fasten Base

When holes are drilled, fasten base to vehicle floor using supplied hardware in the hardware pack. Be sure to tighten all fasteners. [Figure 18-2]

Special Cases

Storage compartment or well can potentially affect lift placement. Most of these situations can be managed with the help of an All Thread Kit. [Figure 19-1]




Figure 19-1

Spare Tire Storage

If the spare tire is stored under the floor, be sure that the base can be bolted through a steel floor or frame.

BASE INSTALLATION / 3rd Row Folding Seats




Figure 20-1

1. Place vertical joiners on back wall of seating well corner. [Figure 20-1]

Use base as template for position.




Figure 20-2

2. Establish height by having mounting holes show over threshold. [Figure 20-2]

Attach joiners using small screws provided to lock height.




Figure 20-3

3. Preferred Installation. Mandatory when lifting heavier payloads.

- Drill two 3/8" holes in floor of well using joiners as template. Fasten 3/8" hardware (x2). [Figure 20-3]

PLUS

- Drill two 3/8" holes through back well wall using joiners as template to accept full-threaded 3/8" bolts.

VERIFY THAT ALL MATING SURFACES ARE FLUSH.

Base Installation / 3rd Row
Folding Seats (con't)**4. Fold third-row seating back into well.**

Verify vertical joiner mount holes are above threshold. [Figure 21-1]




Figure 21-1

5. Attach vertical joiners to base using

supplied hardware as indicated. [Figure 21-2]




Figure 21-2

6. Insert telescoping leg.

Attach swivel leg. Drill or, where possible, use J-hook to seat attachment point and secure leg. [Figure 21-3]

Tighten all fasteners.

continued





Figure 21-3

Base Installation / 3rd Row
Folding Seats (con't)

Exploded View of Assembly for 3rd Row Installation



BASE INSTALLATION / Truck Bed

- 1. Place base in corner of truck bed.** Attempt to position as close to the corner as possible while leaving at least 1" clear around the base on all sides. [Figure 23-1]




Figure 23-1

- 2. Install leg extensions** into base tubes and extend them as far as they will go. The Long Leg Extension should run parallel with the bumper. Set screws can be hand-tightened at this time. [Figure 23-2]




Figure 23-2




USE EXTREME CAUTION! Examine area for obstructions or potential hazards such as gas tank and fuel / brake / electrical lines.

Figure 23-3

- 3. Recommended practice before drilling**

With base in position, use a tape measure to estimate the distance in both directions from an exterior reference point (Ex. outside body panel) to all three potential bolt holes. Repeat this underneath the truck bed. [Figure 23-3]



Check framing, bracing, or other nearby thickened structure on which to mount the lift. Adjust position of base and leg extensions to

capture as much frame as possible while avoiding the vehicle's gas tank, spare tire, suspension components etc.

continued

Base Installation / Base for Truck Bed (con't)




Figure 24-1




Figure 24-2

4. Double-check hole positions for pilot holes.

Mark the three hole locations. Use the base as a template, then remove base. Drill pilot holes down through truck bed in the marked locations. [Figure 24-1]

5. Climb under truck and inspect location of pilot holes.

Again, be sure that the larger hole will avoid the vehicle's gas tank, spare tire, suspension components, etc.

Finish drilling by making 3/8" holes through the truck bed and when possible, through the frame of the truck in the locations shown by the arrows. [Figure 24-1]

Wherever possible, incorporate the frame rails of the truck. This is a requirement when lifting heavier chairs and scooters. [Figure 24-2]

CAUTION!

If incorporating the frame is impossible, large plates (not supplied) may need to be used to spread the force and keep the truck bed from distorting. Call the technical service department for further explanation.



USE EXTREME CAUTION!

Avoid Gas Tank Fuel / Brake / Electrical Lines



6. Drill two more 3/8" holes

for the base leg anchors through the truck bed; if the frame is not captured, if bed material is too thin, and/or application is very heavy.

[Figure 24-1 and 25-1]




Figure 25-1




Figure 25-2

LIFT INSTALLATION

1. **Raise the plastic base cover when the base has been fastened to the vehicle floor, and attach the lift to the base as shown. [Figure 25-1]**
2. **Be sure to compress all split lock washers when tightening all fasteners.**
3. **Cut off remaining All Thread after it is tightened against the washer. This allows nut removal to deburr thread as it is removed. [Figure 25-2]**




Figure 25-1




Figure 25-2

continued

Lift Installation (con't)




Figure 26-1

4. Attach lifting arm as shown according to lift model.
[Figure 26-1]

5. Plug in lifting motor. [Figure 26-2]




Figure 26-2

ADJUSTMENTS : HEIGHT

AL425 / AL435 / AL435T

- Remove bolt.
- Loosen set screws (x4) [Figure 27-1]
- Slide inner vertical post.
- Replace bolt.
- Tighten set screws/ (x4) [Figure 27-2]

AL215 / AL225

- Remove bolt.
- Loosen set screws (x4) [Figure 27-3]
- Replace bolt.
- Tighten set screws (x4) [Figure 27-4]




Figure 27-1




Figure 27-2




Figure 27-3



Figure 27-4

continued




Figure 28-1




Figure 28-2

ADJUSTMENTS : PITCH

AL425


- Remove bolt.
- Rotate turnbuckle.
- Replace bolt. [Figure 28-1]

AL435 / AL435T

- Loosen bolt.
- Remove pin.
- Rotate arm.
- Replace pin.
- Tighten bolt. [Figure 28-2]

NOTE: The AL215 and AL225

are manufactured with a 5 degree pre-load so pitch adjustment is not necessary.



ADJUSTMENTS : ROTATION

AL225 / AL425 / AL435 /

AL 435T The amount of allowable rotation is determined by the cams indicated below. Loosen set screw and rotate as required.

[Figure 28-3]

If installing the lift on the driver side, or if the post rotates in the wrong direction, simply reverse the wires at the rotational motor. [Figure 28-4]

Rotation Limit Switches may also need to be flipped to properly stop the motor. [Figure 28-5]

continued




Figure 28-3

Figure 28-4

Figure 28-5

Lift Adjustments : Rotation (con't)

The average installation will require approximately 180 degrees of rotation. [Figure 29-1]

Set the rotation so that the arm has enough room to transport the mobility device in and out of the vehicle without any contact with the vehicle.



CAUTION!

Do not set the limits to over-rotate the arm. Damage may occur to the vehicle.



Figure 29-1

AL215

The AL215 is manufactured with manual rotation. The base has two set screws which act as mechanical stops to limit the rotation of the arm. [Figure 29-2]




Figure 29-2

When the arm is rotated, it should stop at its full in and out positions. [Figure 29-3]



CAUTION!

Be sure that set screws are in place, but not so tight as to prohibit the arm from rotating.




Figure 29-3

The Docking Device is an interface between the lift and the power chair or scooter.

Most power chairs and scooters can be lifted either by the center seat post or the four-post seat frame.



Figure 30-1



Figure 30-2

Types of Docking Devices

[Figures 30-1 and 30-2]

The Above Docking Devices are two of the most common and can lift most power chairs and scooters. However, many other devices are also available which may be more appropriate to your application.

Please consult the instructions provided with your Docking Device or contact our technical service department to find the specific device that will work best for you.

TROUBLESHOOTING

The following procedures are reserved for the approved installer/dealer. They should not be attempted by anyone without proper knowledge of automotive electrical circuitry.

PROBLEM

Lift does not operate or lift operates slowly or intermittently.

Cause

Bad electrical connection(s) / Circuit breaker

Solutions

- Check / clean all connections that might be loose or dirty. The lift's motor requires quality electrical connections to operate at full capacity; any break in the wiring will slow down the motor and it will deteriorate prematurely.
- Inspect the full length of the wiring harness to ensure the insulation is not torn. The lift's vehicle power harness running through or under the vehicle is subject to road debris and rubbing against the vehicle's frame which can cause a short.
- Verify the circuit breaker. The circuit breaker is located about 6" from the connections to the vehicle's battery. The breaker will self-reset if overloaded; however, verify (with Ohm meter or test light) that the breaker is functioning. Or replace it with a new/known-good circuit breaker and perform the tests shown in Figure 31-2.

PROBLEM

Lifting strap operates in reverse

Cause

Button was held too long and unwound the lifting strap like a yo-yo. The lifting strap wound in reverse.


Solutions

Press the button that extends the strap and continue



Figure 31-1

to hold until the strap returns to the proper direction. Strap should always wrap over the top of the spool. [Figure 31-1]



continued

Figure 31-2

Dealer Only: Troubleshooting (con't)

NOTE: Be cautious when troubleshooting with a test light or voltage meter. You may get a false indication as shown below. [Figure 31-2] It will indicate that a wire connection exists – but it may not necessarily enough.

We strongly recommend that you examine both voltage and current, or isolate sections of the lift wiring using the process of elimination with a known good/fully charged 12V automotive battery or known good/fully charged power chair/scooter battery.



These instruments will detect voltage, but may not indicate a tear or poor connection in the wiring.




Figure 31-2

PROBLEM

Scooter or chair tips front or back while being lifted.

Cause

Chair or Scooter is being lifted off center.

Solution

Adjust for center of gravity on docking device. Check to see if proper docking device is being used.

PROBLEM

Lifting arm is hard to rotate.

Cause

Dry / dirty bushings.

Solution

Clean and lubricate bushings in base with white/lithium grease or equivalent.



Be careful when troubleshooting **CAUTION!** with a test light or voltage meter. They may give false indications.




AUTOMOTIVE TEST LIGHT




VOLTAGE METER

Exploded View AL215




ASSEMBLY PARTS				ASSEMBLY PARTS			
ITEM	QTY	PART NO.	DESCRIPTION	ITEM	QTY	PART NO.	DESCRIPTION
1	1	300-2801-A	BAG COVER ASSEMBLY	7	1	H10-2801-A	HARDWARE KIT, MANUAL BASE MOUNTING
2	1	340-2801-C	SQUARE POST	8	1	402008	1 BUTTON HAND CONTROL
3	1	300-2801-A	ARM ASSEMBLY	9	1	340CS-8_12-16-0_30-Z	WEX HEAD, 1/8-16 X 1.50, ZP
4	1	ALARM03	ALERT HARNESS	10	1	WU10_37-16-0-0-LOCK2	WLOCK NUT, 1/8-16, ZP
5	4	ALARM05	STOCKS, SERIAL NUMBER	11	1	WU10_30-13-0-0-LOCK2	WLOCK NUT, 1/2-13, ZP
6	2	340CS-8_12-16-0_30-Z	BUTTON HEAD, 1/8-16 X 1.50, SS	12	4	SSCR-8_12-16-0_30-Z	SET SCREW 2/8-16 X 0.50, ZP

Exploded View
AL225

ASSEMBLY PARTS				ASSEMBLY PARTS			
ITEM	QTY	PART NO.	DESCRIPTION	ITEM	QTY	PART NO.	DESCRIPTION
1	1	200-1881-A	MOTOR HOUSING ASSEMBLY	30	1	862354	HARNESS (WIRES & SWITCHES NOT SHOWN)
2	1	240-2181-C	SQUARE POST	31	1	862360	BASE COVER
3	1	380-2181-A	ARM ASSEMBLY	32	1	862361	WASHER HEAD, 1/2-12 X 3/8, SS
4	1	577-1016-C	PCB PLATE	33	1	862362	NUT, 3/8-16 NYLOC62
5	2	862363	WASHER, 1" FC from 25 YD ROLL	34	2	862363	NUT, 3/8-16 NYLOC62
6	4	862364	STICKER, SERIAL NUMBER	35	2	862364	NUT, 3/8-16 NYLOC62
7	2	862365	BUTTON HEAD, 1/2-12 X 3/8, SS	36	5	862365	WASHER HEAD, 1/2-12 X 3/8, SS
8	1	862366	HARNESS, QT, POWER BASE MOUNTING	37	2	862366	SPACER, 0.14, 0.02-21, L=0.30, M
9	1	862367	HARD CONTROL - 4 BUTTON	38	4	862367	SET SCREW 1/8-16 X 0.50, 2P


Exploded View AL425



ASSEMBLY PARTS			
ITEM	QTY	PART NO.	DESCRIPTION
1	1	200-2815-A	MOTOR & HOUSING ASSEMBLY
2	1	200-2815-A	COLLAR & POST ASSEMBLY
3	1	200-2815-A	HOIST ASSEMBLY
4	1	570-1005-C	PCB PLATE
5	2	AL425004	VELCRO, 1" PC Foam 25YD ROLL
6	4	AL425005	STICKER SERIAL NUMBER
7	1	BHCS-0_20-15-3_20-SS	BUTTON HEAD, 1/2-13 X 1.00, SS
8	1	H10-2812-A	HARDWARE, KIT, POWER BASE MOUNTING
9	1	840004	HAND CONTROL - 4 BUTTON
10	1	H125100	ROUND TUBE PLUG


ASSEMBLY PARTS			
ITEM	QTY	PART NO.	DESCRIPTION
11	1	8425054	HANGES (WIRE & SWITCH IS NOT SHOWN)
12	1	8425025	BASE COVER
13	1	HWCS-0_37-16-2_25-Z	HEX HEAD, 20-16 X 2.50, ZP
14	1	HWCS-0_28-12-2_25-Z	HEX HEAD, 1/2-12 X 2.25, ZP
15	1	WU70_27-16-WYLOCK-Z	WYLOCK NUT, 20-16, ZP
16	2	WU70_20-12-WYLOCK-Z	WYLOCK NUT, 1/2-12, ZP
17	1	WU74-02-WYLOCK-Z	WYLOCK NUT # 0-02, ZP
18	5	PYMS-0-22-0_25-Z	PNW HEAD, # 6-22 X 0.50, ZP
19	1	SPCR-0_30-0_312-0_30-WYLOCK	SINCRIBED=0.14, OD=27, L=0.14, W
20	4	SDCR-0_37-16-0_25-Z	SET SCREW 20-16 X 0.50, ZP
21	2	WASH-0_28-1_20-0_20-08-Z	ROUND HOLE WASHER 028 (2), ZP

Exploded View AL435




ITEM	QTY	PART NO.	DESCRIPTION	ITEM	QTY	PART NO.	DESCRIPTION
1	1	300-2001-A	MOTOR HOUSING/ASSEMBLY	19	1	910-0-20-A	STICKER
2	1	300-2002-C	AL435 SWIVEL-COLLAR ASSEMBLY	20	1	916-2009-A	FRONT STICKER
3	1	279-2000-A	2 X 60 OFFSHOULDER	21	1	PLATE008	STICKER
4	1	300-2003-A	SHRIVER, UPPER COLLAR	22	2	AL20000	WELDER, 7"PC FOR 30" W/ROLL
5	1	304-2000-A	SWAPFORMER W/SHIMS	23	4	AL40000	BROKER, SERIAL NUMBER
6	1	300-2004-A	SHRIVER, LOWER COLLAR	24	1	910-0003-A	WARNING, EXT. POWER BASE MONITOR
7	1	300-2004-A	SHRIVER, LOWER COLLAR	25	1	100000	BASE CONTROL, BASE TOP
8	1	300-2005-A	LOWER COLLAR RING SHRIVER	26	1	W300-C-30-05-1-00-Z	W/1100-L 30" X 10" C300, 3P
9	1	301-2000-A	SHRIVER, MOTOR W/SHIMS	27	1	W300-C-30-05-1-00-Z	W/1100-L 30" X 10" C300, 3P
10	1	910-2004-A	SWITCH, ON/OFF RED AND BLACK	28	1	W300-C-30-05-1-00-Z	W/1100-L 30" X 10" C300, 3P
11	1	914-2000-A	PCB, ON/OFF W/ON-OFF-SWITCH	29	2	W300-C-30-05-1-00-Z	W/1100-L 30" X 10" C300, 3P
12	1	300-2004-A	SHRIVER, CONTROL, 1 CHANNEL, 7 PIN DIN	30	2	910-0003-A	WARNING, EXT. POWER BASE MONITOR
13	1	478-1000-A	BASE COVER, ALUM.	31	4	100000	BASE CONTROL, BASE TOP
14	1	300-2009-C	COVER, LOWER COLLAR	32	4	910-0003-A	WARNING, EXT. POWER BASE MONITOR
15	1	300-2009-C	COVER, LOWER COLLAR	33	1	910-0003-A	WARNING, EXT. POWER BASE MONITOR
16	1	300-2009-C	COVER, LOWER COLLAR	34	1	910-0003-A	WARNING, EXT. POWER BASE MONITOR
17	1	300-2009-C	COVER, LOWER COLLAR	35	2	910-0003-A	WARNING, EXT. POWER BASE MONITOR
18	1	300-2009-C	COVER, LOWER COLLAR				
19	1	300-2009-C	COVER, LOWER COLLAR				
20	1	300-2009-C	COVER, LOWER COLLAR				
21	1	300-2009-C	COVER, LOWER COLLAR				
22	2	300-2009-C	COVER, LOWER COLLAR				
23	4	300-2009-C	COVER, LOWER COLLAR				
24	1	300-2009-C	COVER, LOWER COLLAR				
25	1	300-2009-C	COVER, LOWER COLLAR				
26	1	300-2009-C	COVER, LOWER COLLAR				
27	1	300-2009-C	COVER, LOWER COLLAR				
28	1	300-2009-C	COVER, LOWER COLLAR				
29	2	300-2009-C	COVER, LOWER COLLAR				
30	2	300-2009-C	COVER, LOWER COLLAR				
31	4	300-2009-C	COVER, LOWER COLLAR				
32	1	300-2009-C	COVER, LOWER COLLAR				
33	1	300-2009-C	COVER, LOWER COLLAR				
34	4	300-2009-C	COVER, LOWER COLLAR				

Exploded View AL435 T




ASSEMBLY PARTS				ASSEMBLY PARTS			
ITEM	QTY	PART NO.	DESCRIPTION	ITEM	QTY	PART NO.	DESCRIPTION
1	1	209-3005-A	MOTOR HOUSING ASSEMBLY	18	1	218-2009-A	INCH/FT STICKER
2	1	275-2009-A	3 COIL LIFTING ARM	20	1	208-2015-C	ALARM POST ASSEMBLY
3	1	309-2009-A	HARNES, UPPER COLLAR	21	1	AL43500	STICKER
4	1	304-2009-A	MAIN POWER HARNES	22	3	AL43500	VALVE, 1" FC BALL BEY TO ROLL
5	1	305-2009-A	HARNES, POWER ALBS	23	4	AL43500	STICKER, SERIAL NUMBER
6	1	306-2009-A	HARNES, LIMIT SWITCH, ALBS	24	1	192-2003-A	HARDWARE, 6CT POWER GATE MOUNTING
7	1	308-2009-A	LOWER COLLAR/CO HARNES	25	1	HW000	HW000 CONTROL, 8 BJT/12H
8	1	307-2009-A	EDUCATIONAL MOTOR HARNES	26	1	HW000	HW000 CONTROL, 8 BJT/12H
9	1	312-2009-A	SWITCH, DROPPED RED-AND BLACK	27	1	HW000	HW000 CONTROL, 8 BJT/12H
10	1	314-2009-A	PCB, CRAYON WORKS, BASE	28	1	HW000	HW000 CONTROL, 8 BJT/12H
11	1	309-3004-A	HARNES, CONTROL, 8 CHANNEL, 1 PH DR	29	2	HW000	HW000 CONTROL, 8 BJT/12H
12	1	410-1005-A	BASE COVER, ALBS	30	2	HW000	HW000 CONTROL, 8 BJT/12H
13	1	058-2000-C	CONTROL, NOX COVER	31	4	HW000	HW000 CONTROL, 8 BJT/12H
14	1	059-2000-C	CONTROL, NOX	32	1	HW000	HW000 CONTROL, 8 BJT/12H
15	1	058-2000-C	CONTROL, NOX COVER	33	1	HW000	HW000 CONTROL, 8 BJT/12H
16	1	071-3003-A	RELAY BOX BRACKET	34	4	HW000	HW000 CONTROL, 8 BJT/12H
17	1	069-2009-A	RELAY BOX COVER	35	2	HW000	HW000 CONTROL, 8 BJT/12H
18	1	218-2009-A	STICKER				

Exploded View AL215 & AL225 Arm



ASSEMBLY IN ITS				ASSEMBLY PARTS			
ITEM	QTY	PART NO.	DESCRIPTION	ITEM	QTY	PART NO.	DESCRIPTION
1	1	281-2801-C	HOIST HOUSING	11	1	ALA67917	LIFTING STRAP
2	1	576-2801-C	HOIST HOUSING COVER	13	1	BHCS-0_25-20-1_75-05	BUTTON HEAD, 1/4-20 x 1.75, SS
3	1	580-2801-C	DETACHABLE HOOK	13	1	BHCS-10-32-4_37	BUTTON HEAD, 10-32 x 3/8
4	1	581-2801-C	HOOK SLEEVE	14	3	BHCS-ME-1_20-10-05	BUTTON HEAD, ME-1 X 10MM, SS
5	1	ALA00111	LIFTING MOTOR	15	2	R225R02	AL215 & AL225 ROLLER
6	1	ALA21028	SPOOL CHAIN 50 LINKS	16	1	MIT-0_20-ACORN-N	ACORN NUT, 1/4-20, NI
7	1	ALA21053	STRAP TAB	17	6	PHTS-8-32-4_25-8Z	FLY HEAD - THREAD FORMING, 8-32 X 0.25, 8Z
8	1	ALA21026	STICKER	18	3	FW0_37-2_30-CL-Z	CLEVIS PIN & SCLIP, 3/8 X 2.50, ZP
9	1	ALA214-PT	SPOOL	19	1	MRSH0_25-0_30-0_36-SL-Z	1/4" SPLIT LOCK WASHER
10	2	ALA21418	FLANGE BUSHING 8R2 20K 1/2X20				


Exploded View AL425 Arm



ASSEMBLY PARTS			
ITEM	QTY	PART NO.	DESCRIPTION
1	1	214-200-F	24 TOOTH SPUR
2	1	301-201-C	HOIST HOLDING
3	1	570-200-C	HOIST HOUSING COVER
4	1	570-200-C	HOIST HOUSING COVER
5	1	573-200-C	HOIST HOUSING COVER - BACK
6	1	580-200-C	DETACHABLE HOOD
7	1	301-200-C	HOCK SLIDE
8	1	042041-PLT	TURNBUCKLE NUT
9	1	042042-PLT	TURNBUCKLE S-COLLARS
10	1	704-200-A	MOTOR, LIFTING, ELECTRIC
11	1	AL425B	1" FLOOR COLUMN BOLTING
12	1	AL425D	STAMP PIN
13	1	AL425E	STROKES
14	2	AL425F	RANGE STOPPING AND STOP/START
15	1	AL425G	LIFTING STRAP

ASSEMBLY PARTS			
ITEM	QTY	PART NO.	DESCRIPTION
16	1	01C3-4, 25-20-1, 25-01	BUTTON HEAD, 1/4-20 x 1.75, 15
17	2	01C3-4, 20-15-4, 25-02	BUTTON HEAD, 1/4-20 x 0.75, 2P
18	1	01C3-4, 20-15-1, 04-01	BUTTON HEAD, 1/4-20 x 0.50, 15
19	1	01C3-10-12-1, 25-03	BUTTON HEAD, 1/4-20 x 0.51, 03
20	5	01C3-04-1, 04-10-01	BUTTON HEAD, 1/4-20 x 0.51, 01
21	1	PH2540	HOIST MOTOR COVER
22	2	PH2544	STAMP ROLLER
23	1	PH2545	PIN, BUSHING, 1/8" x 0.425
24	1	PH0005	SHOULDER BUSHING
25	1	PH00_25-20-4-020004	WORM GEAR, 1/4-20, 40
26	02	PH05-0-13-0, 25-02	PIN HEAD - TURNBUCKLE BOLTING, 0.52 x 0.25, 02
27	1	PH04_07-1, 20-0-2	CLAMP PIN 0.5-CLIP, 3/8 x 0.25, 2P
28	1	PH04_08-1, 25-2	CLAMP PIN 0.5-CLIP, 3/8 x 0.25, 2P
29	1	0027-0, 25-20-0, 025	SET SCREW, 1/4-20 x 0.425
30	1	PH04_25-4, 20-4, 04-02-2	1/4" SPACER LOCK WASHER


Exploded View AL435 Series Arm



ASSEMBLY PARTS			
ITEM	QTY	PART NO.	DESCRIPTION
1	1	290-2001-A	METALWELD HOOK ASSEMBLY
2	1	555-2001-C	MOTOR AND COVER PLATE
3	1	490-2001-A	MOTOR COVER
4	1	275-2001-C	LOWER LIFTING ARM
5	1	278-2001-A	3 TOOTH SPOOL
6	1	280-2001-C	UPPER LIFTING ARM
7	1	378-2001-A	MALE TO FEMALE PINNACLE (NOT SHOWN)
8	2	401-2001-A	LIFTING ARM PLASTIC GUIDE
9	2	478-2001-A	LIFTING SPOOL RUSHING
10	1	558-2001-C	LIFTING ARM REAR COVER
11	1	557-2001-A	MAXI ASSIST LIFTING CRANK
12	1	705-2001-A	420WATT 400V 3-1/2 HP LIFTING MOTOR
13	1	800-2001-A	MAXI ASSIST ACTUATOR (W/REL. SW)
14	1	BLK1055	STRAP TIE
15	1	BLM1007	LIFTING STRAP



ASSEMBLY PARTS			
ITEM	QTY	PART NO.	DESCRIPTION
16	3	BWC1-0-25-30-4-17MM-SS	BUTTON HEAD, NYLON PATCH, 1/4-20 X 0.57, SS
17	1	BWC1-10-05-0-37	BUTTON HEAD, 10-52 X 1/8
18	2	CMMWES	CLIP, 1" 1/4 (BUCKING, 2-4 MM x 1.5)
19	1	CT-144LK	1/2" BLACK WIRE TIE (NOT SHOWN)
20	3	FRME-0-25-30-4-01-01	1/4"-38 X 3/4" FLAT HEAD MACHINE SCREW
21	1	R222M01	AL705 A M.225 ROLLER
22	8	PYHS-6-32-8-25-0-2	FRYHEAD - THERMO FORMING, 6-32 X 8.25, 0-2
23	2	PMH-08-0-31-0P-2	1.69 X 4.50" ROLL PIN
24	1	PMH-325-1-31-0G1-2	ACTUATOR FRONT MOUNTING 3/4" GROOVED CLEARANCE PIN
25	1	PMH-325-1-31-0G1-2	ACTUATOR REAR MOUNTING 3/4" GROOVED CLEARANCE PIN
26	1	PMH-325-2-01-0G1-2	8 ROLLER MOUNTING 3/4" GROOVED CLEARANCE PIN
27	1	PMH-325-3-31-0G1-2	SPOOL MOUNTING 3/4" GROOVED CLEARANCE PIN
28	4	88-8-324C-2	E-CLIP 5/8 SHIRT, 2
29	1	W025-8-32-0-0-16-0105	3/4" W/SHR. .02 DR. .04" THICK



Exploded View AL225, AL425 & AL Series Base




ASSEMBLY			
ITEM	QTY	PART NO.	DESCRIPTION
1	1	20-020-C	AUTOMATIC
2	1	20-020-C	AUTOMATIC COVER
3	1	20-020-C	AUTOMATIC ROLL
4	1	4040-4	FLANG BEARING
5	1	4040-4	COUPLING
6	1	20-020-C	AUTOMATIC-CLAMP
7	2	20-020-C	LIFTING
8	1	20-020-C	WHEEL, WHEEL, 20 1/2x42
9	1	8-000	STEEL, CASTING
10	1	8-000	FLANG BEARING 20x42x12
11	4	802-01-1-011	BUSHING 1/2x1 1/2x1 1/2
12	4	802-01-1-011	BUSHING 1/2x1 1/2x1 1/2
13	3	802-01-1-011	BUSHING 1/2x1 1/2x1 1/2
14	1	8020	AUTOMATIC COVER - A
15	1	8020	AUTOMATIC COVER - B

ASSEMBLY			
ITEM	QTY	PART NO.	DESCRIPTION
16	1	8020A	COVER 200 1/2x145 1/2x 600
17	1	8020B	COVER 200 1/2x145 1/2x 600
18	1	8020C	LIFTING ROLLER 200x 600
19	1	8020D	FLANG 1/2x145x145
20	1	8020E	FLANG 1/2x145x145
21	1	8020F	FLANG 1/2x145x145
22	2	8020G	COVER LIFTING - 200x600
23	1	8020H	COVER LIFTING - 200x600
24	2	7000-01-1-011	FLANG 1/2x145 1/2x145
25	1	802-01-1-010	BUSHING 1/2x1 1/2x1 1/2
26	1	802-01-1-011	1/2x1 1/2x1 1/2
27	1	802-01-1-011	1/2x1 1/2x1 1/2
28	2	102-01-1-011	102-01-1-011
29	2	8001-01-1-011	1/2x1 1/2x1 1/2
30	2	8001-01-1-011	8001-01-1-011
31	2	8001-01-1-011	8001-01-1-011









VEHICLE LIFTS THREE YEAR TRANSFERABLE LIMITED WARRANTY

PLEASE FILL OUT ALL FIELDS AND RETURN A COPY.

Fax completed form to 1-866-234-5680 or mail to Harmar, ATTN: Warranty Department, 2075 47th Street, Sarasota, Florida 34234. You may also register online at www.harmar.com. Keep a copy of this form for your records.

Harmar Mobility warrants its lift products against defects in material, mechanical and electrical components (parts), excluding labor cost, batteries, paint and covers, for a period of three (3) years from date of retail purchase, provided that the products have been installed, maintained and operated properly. This warranty does not cover defects in vehicles on which Harmar products are installed or defects in Harmar products caused by defects in any part of the vehicle upon which the product is installed. This warranty does not cover maintenance or adjustments. Harmar will not be charged for labor, consequential damage or repair expenses. Harmar will not, under any circumstances, be liable for the loss of the use of its products or loss of time. This warranty becomes null and void if the product has been lost, damaged by accident, over-stressed, misused and/or neglected, or if the product has been modified in any way. Defective parts must be returned, prepaid, to Harmar at the address listed above, for inspection prior to credit, repair or replacement, at Harmar's option. Harmar's sole obligation and the exclusive remedy under this warranty is limited to such credit, repair or replacement.

THIS EXPRESS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES OR CONDITIONS, INCLUDING ALL IMPLIED WARRANTIES OR MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, AND THERE ARE NO WARRANTIES THAT EXTEND BEYOND THE DESCRIPTION OF THE LIMITED WARRANTY DESCRIBED HEREIN. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS AND YOU MAY ALSO HAVE OTHER LEGAL RIGHTS WHICH VARY FROM STATE TO STATE.

PRODUCT INFORMATION

Model: _____
Serial Number: _____
Purchase Date: _____

INSTALLER INFORMATION

Company Name: _____
Contact Name: _____
Address: _____

Phone: _____
Fax: _____
Email: _____

APPLICATION INFORMATION

Scooter Power Chair Wheelchair
Year: _____
Manufacturer: _____
Model: _____

PURCHASER INFORMATION

Name: _____
Address: _____

Phone: _____
Email: _____

ADDITIONAL INFORMATION

How did you hear about Harmar?

- Harmar Dealer Friend or Acquaintance
 Internet Saw Harmar product somewhere
 Magazine Other _____

Which _____

Do you have internet access? Yes No

I purchased my Harmar lift because of?

- Style/Appearance
 Harmar Representative
 Previous Experience
 Ease of Use
 Recommendation
 Price/Value

Inside Lifts

Installation & Owner's Manual



Harmar.

America's Lift Leader™

www.harmar.com | 800-833-0478

2075 47th Street Sarasota, Florida 34234